


# Oven Maintenance and Seal Removal

There is a rubber seal surrounding the oven opening (as shown in the photograph) which is necessary to ensure the correct operation of the oven.

It is good practice to regularly check the condition of the seal.

The best way to clean the seal would be to remove it from the oven and **let it soak in a container of warm soapy water before cleaning it. Avoid using abrasive tools or products.**



## Oven Seal Removal

In each corner of the seal is a clip which holds it in place, these four clips can be easily unattached from the oven opening (larger ovens may have more clips).

When putting the seal back on the oven, make sure that the longest edge of the seal goes on the top and bottom of the opening.



Hole for seal clip



Seal clip

**If the seal is found to be damaged or has become hard, do not use the oven. Contact our service centre and wait until it has been replaced.**